



FLOUT® Dosing Chamber
 RECOMMENDED MINIMUM DIMENSIONS for
 an 8" drawdown FLOUT®

Minimum width of chamber 12"

Multiple outlet Flout® body is 8 inches per
 section. Outlet pipes 8 inches ON CENTER.
 Total minimum width of chamber is
 number of outlets x 8 inches plus 4
 inches.

Avoid placing INLET over the Flout®.
 Provide a baffle to 4 inches off floor if
 necessary.

Flout® and Floating Outlet® are registered
 trademarks for a dosing apparatus
 manufactured under US Patent No.5290434
 by :

Rissy Plastics, LLC
 350 Cedar Lane
 Torrington, CT 06790
 860-482-1645
 rissyplastics.com
 tanxrus@aol.com